

FracTank.™

DEPLOYMENT SYSTEM (FTDS)



EASY SET-UP AND KNOCK DOWN

SEI's FRAC tank is designed for storing large volumes of water for use in hydraulic fracturing. Using our new deployment system, tanks can be easily set-up with only a crew of four people and with almost no site preparation.

SEI's FRAC tanks are lightweight and fully collapsible, offering liquid containment capacity many times larger than their transportable size.

FAST, CONVENIENT DEPLOYMENT

One of the biggest challenges facing collapsible tanks are the objections from frac crews who have to roll and unroll the tanks.

Traditionally, with metal frac tanks, crew members only have to connect a few hoses while the remainder of the tank deployment is done by truck or crane.

Fortunately, SEI's frac tanks offer a small-crew deployment system that limits the use of extra manpower or physical activity to unroll and roll-up the bladder.

Using a bobcat and hydraulic power to roll and unroll a tank, SEI's Frac Tank Deployment System (FTDS) drastically reduces crew effort and allows for easier and faster set-up and knock down times.

- Set-Up – unroll an empty tank using only a small crew.
- Knock Down – fold and roll a tank that contains residual water (automatically squeezed out of purpose-built draining ports).

MAKE DEPLOYMENT EASY WITH THE FTDS

- Drastically reduce crew size and effort
- Prevent injury to crew members
- Reduce abrasion (no dragging of the tank)
- Squeeze excess water out of the tank easily
- Roll tanks smaller and tighter to fit back into reusable crates
- FTDS adjustable spreader bar enables easy access
- Removable roller bar can be used on multiple tanks
- Roller guides and pipes make sure the tank glides smoothly on and off
- Roller tubes remain inside the rolled up tank for easy connection at a new location
- Comes with a universal bobcat mounting plate with hydraulic connections
- Roller connects to auxiliary hand controls on the bobcat
- Painted in high-visibility orange color



Fractank™

DEPLOYMENT SYSTEM (FTDS)



SET-UP AND KNOCK DOWN IN SIX SIMPLE STEPS



1. Fold the tank as shown above and attach straps (supplied).



2. Guide the tank end between the FTDS rollers.



3. Activate the FTDS hydraulic scissors to grip the tank.



4. Roll up the tank by driving the bobcat forward. Water is squeezed out as the tank is rolled up.



5. Once finished rolling, the tank is ready to be secured into its lifting harness.



6. Release the FTDS, remove the roller bars and leave the tubes inside for future use.